



RO

MANUAL INSTRUCȚIUNI

Pentru modelele:

D10-25VD1(O)/(U)


D15-25VD1(O)/(U)

D30-25VD1(O)/(U)

D10-20VD1(O)/(U)

D15-20VD1(O)/(U)

D25-20VD1(O)/(U)



Desenul de mai sus este doar pentru referință. Aspectul produsului real este cel standard.

Felicitati pentru achizitie. Inainte de a-l instala si utiliza, varugam sa cititi cu atentie acest manual si sa-l pastrati pentru referinte ulterioare.



Observatie generala

- Instalarea si intretinerea trebuie efectuate de catre profesionisti calificati sau de catre tehnicieni autorizati Midea.
- Producatorul nu va fi responsabil pentru nici o dauna sau defectiune cauzata de o instalare gresita sau de nerespectarea urmatoarelor instructiuni incluse in acest manual.
- Pentru instructiuni mai detaliate de instalare si intretinere, va rugam sa consultati capitolele de mai jos.

CUPRINS


TITLU	PAG.
1.Precautii	(2)
2.Introducere produs	(3)
3.Instalare unitate	(5)
4.Metode de utilizare.....	(7)
5.Intretinere	(8)
6.Defectiuni, cauze, remedieri	(9)

1. ATENTIE

Înainte de a instala acest boiler electric, verificați și confirmați ca împământarea de la priza de alimentare este executată în mod corect. În caz contrar, încălzitorul electric de apă nu poate fi instalat și utilizat. Nu folosiți prelungitoare. Instalarea și utilizarea incorectă a acestui încălzitor electric de apă, poate duce la răni grave și pierderea bunurilor.

Precauții Speciale

- Acest aparat nu este destinat utilizării de către persoane (inclusiv copii) cu capacități fizice, senzoriale sau mentale reduse sau cu lipsa de experiență și cunoștințe, cu excepția cazului în care acestea au fost instruite cu privire la utilizarea aparatului de către o persoană responsabilă pentru siguranța lor. Copiii trebuie supravegheați pentru a se asigura că nu se joacă cu boilerul.
- Acest încălzitor electric de apă va fi instalat pe un perete solid. Dacă rezistența peretelui nu poate suporta o sarcină egală cu de două ori greutatea totală a încălzitorului umplut complet cu apă, atunci este necesar să instalați un suport special.
- Priza de alimentare trebuie executată în mod corect. Curentul nominal al prizei nu trebuie să fie mai mic de 16A. Înălțimea de instalare a prizei de alimentare nu trebuie să fie mai mică de 1,8 m. Priza și stecherul trebuie să fie uscate pentru a preveni scurgerile electrice. Dacă, cablul flexibil de alimentare este deteriorat, acesta trebuie înlocuit cu cablul de alimentare special furnizat de producător, de către personal calificat.
- Pentru funcționarea corectă a aparatului este necesar ca presiunea maximă de intrare a apei să fie de 0,5 MPa iar presiunea minimă de intrare a apei să fie de 0,1 MPa.
- Când utilizați boilerul pentru prima dată (sau la prima utilizare după întreținere), acesta nu poate fi pornit până când nu este umplut complet cu apă. La umplerea cu apă, cel puțin una dintre supapele de evacuare de la ieșire trebuie să fie deschisă pentru a evacua aerul. Această supapă poate fi închisă după ce boilerul a fost umplut complet cu apă.
- Supapă de limitare a presiunii atașată la încălzitor trebuie instalată la intrarea de apă rece a acestui încălzitor și asigurați-vă că nu este expusă la abur. Apa poate fi scursă prin supapă de limitare presiune, conducta de evacuare trebuie să se deschidă larg în atmosferă. Apa din recipientul interior poate fi evacuată departe de supapă de eliberare a presiunii. Rasuciti surubul filetat al supapei de eliberare a presiunii și ridicați manerul de scurgere în sus (vezi Fig.1). Conducta de drenaj conectată la orificiul de eliberare a presiunii trebuie menținută înclinată în jos și într-un mediu ferit de îngheț. Apa poate picura din conducta de refulare a dispozitivului de reducere a presiunii. Conducta trebuie lăsată deschisă în atmosferă.
- În timpul încălzirii, pot apărea picături de apă din orificiul de eliberare a presiunii al supapei de presiune. Acesta este un fenomen normal. În caz de scurgeri abundente, vă rugăm să contactați centrul de asistență pentru clienți. Acest orificiu de eliberare a presiunii nu trebuie, în niciun caz, blocat; în caz contrar, boilerul poate fi deteriorat, ducând chiar la accidente.
- - Supapă de limitare presiune trebuie verificată și curățată regulat, pentru a vă asigura că nu este blocată.
- Temperatura apei din interiorul boilerului poate ajunge până la 75°C, corpul uman nu trebuie expus la apa caldă atunci când este utilizată inițial. Apa caldă se reglează la o temperatură adecvată pentru evitarea opăririi.
- Dacă vreă piesă sau componente ale acestui boiler electric de apă sunt deteriorate, vă rugăm să contactați centrul de asistență pentru clienți pentru reparații.
- Prizele de extensie sunt interzise.
- Vă rugăm să deconectați energia înainte de întreținere.
- Acest aparat a fost proiectat doar pentru uz casnic și poate cauza pericole dacă este utilizat în ocazii speciale.



2. INTRODUCERE -1

2.1 Nomenclatura

D	*	-	*	*	*
①	②		③	④	⑤

- ① este codul de produs al boilerului electric cu acumulare;
 ② este capacitatea (L);
 ③ reprezintă puterea nominală (*100W);
 ④ reprezintă codul modelului (de exemplu: A,B,C...);
 ⑤ reprezintă extensia modelului (ex: 1,2,3...);




NOTA

Acest manual este aplicabil incalzitoarelor electrice de apa cu acumulare (D *-****) produse de aceasta companie.

2.2 Parametri performanta tehnica

Model	Volum (L)	Putere nominala (W)	Tensiune nominala (ACV)	Presiune nominala (MPa)	Temperatura nominala apa (°C)	Termostat nominal SET (°C)	Clasa protectie	Grad impermeabilitate
D10-25VD1(O)/(U)	10	2500	220-240	0.75	75	75	I	IPX4
D15-25VD1(O)/(U)	15	2500	220-240	0.75	75	75	I	IPX4
D30-25VD1(O)/(U)	30	2500	220-240	0.75	75	75	I	IPX4
D10-20VD1(O)/(U)	10	2000	220-240	0.75	75	75	I	IPX4
D15-20VD1(O)/(U)	15	2000	220-240	0.75	75	75	I	IPX4
D25-20VD1(O)/(U)	25	2000	220-240	0.75	75	75	I	IPX4


2.3 Scurta introducere a structurii produsului



	10L	15L	30L / 25L
A	324	368	440
B	324	368	440
C	300	316	402
D	66	66	66

(Nota: Toate dimensiunile sunt in mm)


2.4 Diagrama cablurilor interne




3 INSTALARE UNITATE

3.1 Instructiuni Instalare

- ① Acest incalzitor electric de apa va fi instalat pe un perete solid. Daca rezistenta peretelui nu poate suporta o sarcina egala cu de doua ori greutatea totala a incalzitorului umplut complet cu apa, atunci este necesar sa instalati un suport special.
In cazul peretelui de caramizi goale, asigurati-va ca il umpleti complet cu beton.
- ② Dupa selectarea unei locatii adecvate, determinati pozitiile celor doua gauri de instalare utilizate pentru conexiunile cu carlig (200 mm), faceti doua gauri in perete cu adancimea corespunzatoare utilizand un burghiu cu dimensiunea care se potriveste cu conexiunile atasate, introduceti suruburile, indreptati carligul in sus, strangeti piulitele pentru a se fixa ferm si apoi atarnati boilerul electric de el (vezi Fig.2).





- ③ Instalati priza de alimentare in perete. Cerintele pentru priza sunt urmatoarele: 250V/10A, monofazat, trei conexiuni. Este recomandat sa plasati priza in partea dreapta sus deasupra boilerului. Inaltimea prizei pana la sol nu trebuie sa fie mai mica de 1,8 m (vezi Fig.3).



- ④ Daca baia este prea mica, incalzitorul poate fi instalat in alt loc. Totusi, pentru a reduce pierderile de caldura in conducte, boilerul se instaleaza cat mai aproape de locul de utilizare.


3.2 Conectare conducte


- ① Dimensiunea fiecarei parti de teava este G1/2". Presiunea maxima la intrare trebuie masurata in Pa. Presiunea minima la intrare trebuie masurata in Pa.
- ② Conectarea supapei de limitare a presiunii cu incalzitorul la intrarea incalzitorului de apa.
- ③ Pentru a evita scurgerile la conectarea conductelor, garniturile de etansare din cauciuc furnizate cu boilerul trebuie adaugate la capatul filetelor pentru a asigura etanseitatea imbinarilor.



(Fig.4)

- ④ Dacă utilizatorii doresc să realizeze un sistem de alimentare cu mai multe cai, consultați metoda prezentată în fig.5 pentru conectarea conductelor.





(Fig.5)



NOTA

Asigurați-vă că utilizați accesoriile furnizate de compania noastră pentru a instala acest boiler electric. Boilerul nu poate fi instalat decât pe un suport ferm. În caz contrar, boilerul poate cădea de pe perete și se va deteriora putând produce accidente grave. La determinarea pozițiilor orificiilor pentru suruburi, se va asigura că există un spațiu liber nu mai mic de 0,2 m pe partea dreaptă a boilerului, pentru a ușura întreținerea dacă este necesară.

4. METODE DE UTILIZARE


- Mai întâi, deschideți oricare dintre supapele de evacuare de la ieșirea incalzorului de apă, apoi deschideți robinetul de admisie. Boilerul se umple cu apă. Când apa curge din conducta de evacuare înseamnă că boilerul a fost umplut complet cu apă, iar supapa de evacuare poate fi închisă.



NOTA

În timpul funcționării normale, supapa de admisie trebuie să fie întotdeauna deschisă.

- Introduceți stecherul de alimentare în priză.
- Indicatorul se va aprinde. Termostatul va controla automat temperatura. Când temperatura apei în interiorul boilerului a atins temperatura setată, se va opri automat iar când temperatura apei scade sub cea setată, boilerul va porni automat pentru a relua încălzirea.



(Fig.6)

- ① Rotiti butonul pentru a regla temperatura. Aceasta creste la rotirea spre dreapta si descreste la rotirea spre stanga.
- ② La pornire aparatul se incalzeste atunci cand indicatorul luminos de alimentare este galben. Indicatorul luminos (de incalzire) se stinge atunci cand procesul de incalzire este terminat, la oprire.

5. INTRETINERE




AVERTIZARE

Inainte de a efectua intretinerea, va rugam sa intrerupeti alimentarea cu energie electrica.

- Verificati stecherul si priza de alimentare cat mai des posibil. Trebuie asigurata impamantarea si un contact electric sigur. Stecherul si priza nu trebuie sa se incalzeasca excesiv.
- Daca boilerul nu este utilizat pentru o perioada lunga de timp, in special in regiunile cu temperatura scazuta a aerului (sub 0 °C) este necesar sa se scoata apa din el pentru a preveni deteriorarea. (Consultati Atentionari din acest manual pentru metoda de scurgere a apei din recipientul interior).
- Pentru a asigura o functionare de lunga durata si fiabila a boilerului, recomandam curatarea cu regularitate a interiorului si indepartarea depunerilor de pe elementul de incalzire. Verificati starea anodului de magneziu (complet descompus sau nu) si daca este necesar inlocuiti-l cu unul nou (in caz de descompunere completa). Frecventa curatarii rezervorului depinde de duritatea apei de pe teritoriul (zona, regiunea, tara) utilizatorului. Curatarea trebuie efectuata de catre personal autorizat. Cereti vanzatorului adresa celui mai apropiat centru service.
- Boilerul este echipat cu un intrerupator termic, care intrerupe alimentarea cu energie electrica a elementului de incalzire la supraincalzirea apei sau la absenta acesteia in incalzitorul de apa. Daca boilerul este conectat la retea, dar apa nu este incalzita si indicatorul nu se aprinde, atunci comutatorul termic a fost oprit sau nu a fost pomit. Pentru a reseta boilerul la starea de functionare, este necesar sa:

1. Deconectati boilerul, scoateti placa capacului lateral/inferior.
2. Apasati butonul, situat in centrul comutatorului termic, vezi Fig.7.
3. Daca butonul nu este apasat si nu se face clic, atunci trebuie sa asteptati pana ce comutatorul termic se raceste la temperatura initiala.

Buton resetare manuala



(Fig.7)



AVERTIZARE

Persoanele necalificate nu au voie sa demonteze comutatorul termic pentru a-l reseta. Va rugam sa contactati un service autorizat pentru intretinere. In caz contrar, compania noastra nu isi asuma nici un fel de responsabilitate daca se intampla vreun accident sau pentru pierderea calitatii aparatului.

6. Defectiuni, cauze, remedieri

Erori	Cauze	Remedieri
Indicatorul luminos de incalzire este stins.	Defectiuni ale regulatorului de temperatura.	Contactati personal calificat pentru reparatii.
Nu iese apa din iesirea de apa calda.	1. Alimentarea cu apa curenta este intrerupta. 2. Presiunea hidraulica este prea scazuta. 3. Supapa de admisie a apei curente nu este deschisa.	1. Asteptati restabilirea alimentarii cu apa curenta. 2. Folositi din nou incalzitorul cand presiunea hidraulica creste. 3. Supapa de admisie a apei curente nu este deschisa.
Temperatura apei este prea mare.	Defectiuni ale sistemului de control al temperaturii.	Contactati personal calificat pentru reparatii.
Scurgeri apa	Probleme de etansare a imbinarii fiecărei conducte.	Etansati imbinarile.




NOTA

Partile ilustrate in acest manual de utilizare si intretinere sunt doar orientative, piesele furnizate impreuna cu produsul pot diferi de ilustratii. Acest produs este destinat numai pentru uz casnic. Specificatiile pot fi modificate fara notificare.

Produsul poate fi modificat fara notificare.
Va rugam sa pastrati manualul in mod corespunzator

Instruction Manual

For Model: D10-25VD1(O)/(U) D10-20VD1(O)/(U)
D15-25VD1(O)/(U) D15-20VD1(O)/(U)
D30-25VD1(O)/(U) D25-20VD1(O)/(U)



The picture above is just for reference Please consider the appearance of the actual product as the standard.

Congratulations! You are now a proud owner of Midea water heater. We assure you that this product conforms to the highest standards of quality. Before installing and operating your water heater, please read this manual carefully and keep it for future reference.



General Remark

- The installation and maintenance has to be carried out by qualified professionals or Midea authorized technicians.
- The manufacturer shall not be held responsible for any damage or malfunction caused by wrong installation or failing to comply with following instructions included in this pamphlet.
- For more detailed installation and maintenance guidelines, please refer to below chapters.

TABLE OF CONTENTS


<u>TITLE</u>	<u>PAGE</u>
1.Cautions	(2)
2.Product introduction	(3)
3.Unit installation	(5)
4.Methods of using	(7)
5.Maintenance	(8)
6.Troubleshooting	(9)

1. CAUTIONS

Before installing this water heater, check and confirm that the earthing on the supply socket is reliably grounded. Otherwise, the electrical water heater can not be installed and used. Do not use extension boards. Incorrect installation and use of this electrical water heater may result in serious injuries and loss of property.

Special Cautions

- The water heater is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instructions concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the heater.
- The wall in which the electrical water heater is installed must be able to bear the load more than two times of the heater filled fully with water without distortion and cracks. Otherwise, other strengthening measures must be adopted.
- The supply socket must be earthed reliably. The installation height of the supply socket must not be lower than 1.8m. The rated current of the socket must not be lower than 16A. The socket and plug must be kept dry to prevent electrical leakage. If the flexible power supply cord is damaged, the special supply cord provided by the manufacturer must be selected, and replaced by the professional maintenance personnel.
- The maximum inlet water pressure is 0.5MPa; the minimum inlet water pressure is 0.1MPa, if this is necessary for the correct operation of the appliance.
- When using the heater for the first time (or the first use after maintenance), the heater can not be switched on until it has been filled fully with water. When filling the water, at least one of the outlet valves at the outlet of the heater must be opened to exhaust the air. This valve can be closed after the heater has been filled fully with water.
- The pressure relief valve attached with the heater must be installed at the cold water inlet of this heater, and make sure it is not exposed in the foggy. The water may be outflowed from pressure relief valve, so the outflow pipe must open wide in the air. In order to drain away the water inside the inner container, it can be drained away from the pressure release valve. Twist the thread screw of the pressure release valve off, and lift the drain handle upwards (See Fig.1) . The drainage pipe connected to the pressure release hole must be kept sloping downwards and in a frost-free environment. The water may drip from the discharge pipe of the pressure-relief device and that this pipe must be left open to the atmosphere.
- During heating, there may be drops of water dripping from the pressure release hole of the pressure relief valve, this is a normal phenomenon. The pressure release hole shall not be blocked under no circumstances, otherwise, the heater may get damaged, even resulting in accidents. If there is a large amount of water leak, please contact customer care center for repair.
- The pressure relief valve need to be checked and cleaned regularly, so as to make sure it will not be blocked.
- Since the water temperature inside the heater can reach up to 75°C hot water must not be exposed to human bodies when it is initially used. Adjust the water temperature to a suitable temperature to avoid scalding.
- If any parts and components of this electrical water heater are damaged please contact customer care center for repair.
- Extension sockets are forbidden.
- Please cut off the power before maintenance.
- This appliance has been designed for home use only, and may cause danger if used in special occasions.



2. PRODUCT INTRODUCTION

2.1 Nomenclature

D ***** **-** ***** ***** *****
 ① ② ③ ④ ⑤

- ① is the product code of the storage electric water heater;
- ② is the capacity (L);
- ③ represents the rated power (*100W);
- ④ represents the pattern code (eg : A,B,C...);
- ⑤ represents the extension of pattern (eg : 1,2,3...);




NOTE

This manual is applicable to the storage electric water heaters (D *-***) manufactured by this company.

2.2 Technical Performance Parameters

Model	Volume (L)	Rated Power (W)	Rated Voltage (ACV)	Rated Pressure (MPa)	Rated Water Temperature (°C)	Rated Thermostat SET (°C)	Protection Class	Waterproof Grade
D10-25VD1(O)/(U)	10	2500	220-240	0.75	75	75	I	IPX4
D15-25VD1(O)/(U)	15	2500	220-240	0.75	75	75	I	IPX4
D30-25VD1(O)/(U)	30	2500	220-240	0.75	75	75	I	IPX4
D10-20VD1(O)/(U)	10	2000	220-240	0.75	75	75	I	IPX4
D15-20VD1(O)/(U)	15	2000	220-240	0.75	75	75	I	IPX4
D25-20VD1(O)/(U)	25	2000	220-240	0.75	75	75	I	IPX4


2.3 Brief introduction of product structure



	10L	15L	30L / 25L
A	324	368	440
B	324	368	440
C	300	316	402
D	66	66	66

(Note:All dimensions are in mm)


2.4 Internal Wire Diagram




3. UNIT INSTALLATION

3.1 Installation Instruction

- ① This electrical water heater shall be installed on a solid wall. If the strength of the wall cannot bear the load equal to two times of the total weight of the heater filled fully with water, it is then necessary to install a special support.
In case of hollow bricks wall, ensure to fill it with cement concrete completely.
- ② After selecting a proper location, determine the positions of the two install holes used for expansion bolts with hook (200mm). Make two holes in the wall with the corresponding depth by using a chopping bit with the size matching the expansion bolts attached with the machine, insert the screws, make the hook upwards, tighten the nuts to fix firmly, and then hang the electrical water heater on it (see Fig.2).





- ③ Install the supply socket in the wall. The requirements for the socket are as follows: 250V/10A single phase, three electrodes. It is recommended to place the socket on the right above the heater. The height of the socket to the ground shall not be less than 1.8m (see Fig.3).



- ④ If the bathroom is too small, the heater can be installed at another place. However, in order to reduce the pipeline heat losses, the installation position of the heater shall be as close to the location shall be as near as possible to the heater.


3.2 Pipelines Connection


- ① The dimension of each pipe part is G1/2" ; The massive pressure of inlet should use Pa as the unit; The minimum pressure of inlet should use Pa as the unit.
- ② Connection of pressure relief valve with the heater on the inlet of the water heater.
- ③ In order to avoid leakage when connecting the pipelines, the rubber seal gaskets provided with the heater must be added at the end of the threads to ensure leak proof joints (see Fig.4).



(Fig.4)

- ④ If the users want to realize a multi-way supply system, refer to the method shown in fig.5 for connection of the pipelines.





(Fig.5)



NOTE

Please be sure to use the accessories provided by our company to install this electric water heater. This electric water heater can not be hung on the support until it has been confirmed to be firm and reliable. Otherwise, the electric water heater may drop off from the wall, resulting in damage of the heater, even serious accidents of injury. When determining the locations of the bolt holes, it shall be ensured that there is a clearance not less than 0.2m on the right side of the electric heater, to convenient the maintenance of the heater, if necessary.

4. METHODS OF USING


- First, open any one of the outlet valves at the outlet of the water heater, then, open the inlet valve. The water heater gets filled with water. When water flows out of the outlet pipe it implies that the heater has been filled fully with water, and the outlet valve can be closed.



NOTE

During normal operation, the inlet valve shall be always kept open.

- Insert the supply plug into the socket.
- If the indicator lights up, the thermostat will automatically control the temperature. When the water temperature inside the heater has reached the set temperature, it will switch off automatically, when the water temperature falls below the set point the heater will be turned on automatically to restore the heating.



- ① Rotate the knob according to the marking on the knob to increase or decrease the setting temperature.
- ② In a power-on state, the machine is heating when the Power indicator light is yellow. The Heating indicator light goes out when the heating process is finished, in the insulating state.

5. MAINTENANCE




WARNING

Do cut off power supply before maintenance, to avoid danger like electric shock.

- Check the power plug and outlet as often as possible. Secure electrical contact and also proper grounding must be provided. The plug and outlet must not heat excessively.
- If the heater is not used for a long time, especially in regions with low air temperature (below 0°C), it is necessary to drain water from the heater to prevent damage of the water heater, due to water freezing in the internal tank. (Refer Cautions in this manual for the method to drain away the water from the inner container).
- To ensure long reliable water heater operation, it is recommended to regularly clean the internal tank and remove deposits on the electric heating element of the water heater, as well as check condition (fully decomposed or not) of the magnesium anode and, if necessary, replace it with a new one in case of full decomposition. Tank cleaning frequency depends on hardness of water located in this territory. Cleaning must be performed by special maintenance services. You can ask the seller for address of the nearest service center.
- The water heater is equipped with a thermal switch, which cuts off power supply of the heating element upon water overheating or its absence in the water heater. If the water heater is connected to the mains, but water is not heated and the indicator doesn't light up, then the thermal switch was switched off or not switched on. To reset the water heater to the operating condition, it is necessary to:
 1. De-energize the water heater, remove the plate of the side/lower cover.
 2. Press the button, located at the center of the thermal switch, see Fig.7;
 3. If the button is not pressed and there is no clicking, then you should wait until the thermal switch cools down to the initial temperature.

Manual reset button



(Fig.7)



WARNING

Non-professionals are not allowed to disassemble the thermal switch to reset. Please contact professionals to maintain. Otherwise our company will not take responsibility if any quality accident happens because of this.

6. TROUBLESHOOTING

Failures	Reasons	Treatment
The heating indicator light is off.	Failures of the temperature controller.	Contact with the professional personnel for repair.
No water coming out of the hot water outlet.	1. The running water supply is cut off. 2. The hydraulic pressure is too low. 3. The inlet valve of running water is not open.	1. Wait for restoration of running water supply. 2. Use the heater again when the hydraulic pressure is increased. 3. Open the inlet valve of running water.
The water temperature is too high.	Failures of the temperature control system.	Contact with the professional personnel for repair.
Water leak.	Seal problem of the joint of each pipe.	Seal up the joints.



NOTE

Parts illustrated in this use and care manual are indicative only, parts provided with the product may differ with illustrations. This product is intended for household use only. Specifications are subject to change without notice.

Produsul poate fi modificat si imbunatatit, fara o notificare prealabila.
Pastrati manualul pentru referiri ulterioare